

Advanced Classic Designer Kustodian ION 119 (New Math)

File • Reports • Show • History Export Excel Disable Help Email Pattern

Open Pattern In Patterns Folder: Open Pattern In Archive Folder:

Pattern Name: from Patterns Folder
RAINBOW STREET BOWLTECH VERSION

Settings **Overhead**

Click on item in Initial Pattern Values Grid below to edit

Oil Pump Volume	50
Forward Oil Distance	41
Reverse Start Oil Distance	32
Oil Only Dist	1
Start Bush	0

Forward Loads

Start	Stop	Loade	Speed	End
2L	2R	1	10	1

Add Cancel

Select row and right click row to see menu.

	Start	Stop	Loade	Speed	Crossed	Start	End	Feet	T.Oil
1	2L	2R	2	14	74	0.0	1.9	1.9	3700
2	9L	9R	2	14	46	1.9	5.8	3.9	2300
3	10L	10R	2	18	42	5.8	10.9	5.1	2100
4	11L	11R	1	22	19	10.9	14.0	3.1	950
5	13L	13R	3	22	45	14.0	23.3	9.3	2250
6	14L	14R	1	22	13	23.3	26.4	3.1	650
7	2L	2R	0	26	0	26.4	41.0	14.6	0

Reverse Loads

Start	Stop	Loade	Speed	End
2L	2R	1	10	0

Add Cancel

Select row and right click row to see menu.

	Start	Stop	Loade	Speed	Crossed	Start	End	Feet	T.Oil
1	2L	2R	0	30	0	41.0	32.0	-9.0	0
2	13L	13R	3	18	45	32.0	24.4	-7.6	2250
3	12L	12R	3	18	51	24.4	16.8	-7.6	2550
4	11L	11R	3	18	57	16.8	9.2	-7.6	2850
5	10L	10R	2	14	42	9.2	5.3	-3.9	2100
6	9L	9R	2	10	50	5.3	2.5	-2.8	2500
7	2L	2R	0	10	0	2.5	0.0	-2.5	0

Rules

Item	2-5L:16L-20	6-10L:16-20	11-15L:16L-20	16L-20:20-16R	16L-20:20-16R	20-16R:15-11R	20-16R:10-6R	20-16R:5-2R
Amper Zone Ratio	100	240	1020	1200	1200	1020	240	100
Track Ratio	12	6	1.18	1	1	1.18	6	12

Item	2L-7L:18L-18R	8L-12L:18L-18R	13L-17L:18L-18R	18L-18R:17R-13R	18L-18R:12R-8R	18L-18R:7R-3R
Description	Outside Track Middle	Middle Track Middle	Inside Track Middle	Middle Inside Track	Middle Middle Track	Middle Outside Track
Track Zone Ratio	12	3.36	1.03	1.03	3.36	12

